

Flexible Air Stone Instructions

To ensure proper distribution of air, please ensure that:

- a) the stone is clean
- b) the stone is at a consistent depth in the water
- c) sharp bends are avoided

Failure to maintain a consistent depth across the length of the stone, or overly-sharp bends, can cause a lack of consistent air distribution. If you are experiencing a lack of air distribution in certain areas of the stone try modifying the bends, verifying the stone's depth, or cleaning the stone as instructed on the packaging.

